

FARM2000 BOILER TROUBLE-SHOOTING GUIDE

(v5.0 051016) Yellow

Condition	Probable Cause	Remedy
<p>1. Poor Combustion / Excessive Smoke / Tar Deposits</p>	<p>a) Too much fuel loaded into boiler.</p> <p>b) Excessive moisture in fuel</p> <p>c) Poor flame establishment prior to starting fan</p> <p>d) Poor combustion immediately <u>after</u> fan started (<i>usually due to excess moisture in fuel</i>)</p> <p>e) Insufficient Secondary Air</p> <p>f) Chimney dirty or partially blocked</p> <p>g) Tubes and flue box not cleaned adequately causing back pressure</p> <p>h) Damper in flue box not fully open</p> <p>i) Chimney too short or of poor design</p> <p>j) Boiler Thermostat set too low</p> <p>k) Fan speed set too low</p> <p>l) Fan stopped too soon, causing boiler to idle.</p> <p>m) Boiler too large for heat demand or accumulator too small</p> <p>n) Auxiliary timer incorrectly set, cutting off secondary air prematurely.</p>	<p>Reduce quantity. See page 17</p> <p>Change fuel/fuel storage method and/or season fuel for longer period</p> <p>Using small amount of kindling, light fire at bottom, front centre of fuel load and allow a good fire to establish using natural draft with small stoker door open. Could take 2 - 3 minutes. If flame does not establish readily, indicates damp fuel.</p> <p>Increase fan speed gradually over 5-10 minutes until operating speed is established to prevent excess air “blowing” fire out.</p> <p>Adjust air diverter plate to increase front secondary air (<i>i.e. over-fire air</i>) Ensure rear air spreader not covered by fuel.(HTR boiler models only)</p> <p>Inspect and clean chimney</p> <p>Clean tubes 1/week, and flue box every 2 weeks (<i>with vacuum cleaner or thick glove</i>)</p> <p>Ensure it <u>is</u> fully open</p> <p>Modify chimney layout/Consult FARM2000. See pages 5, 6, 7</p> <p>Increase boiler CONTROL thermostat to 82 - 85°C</p> <p>Increase fan speed</p> <p>Adjust loading frequency and fuel charge to allow fan to run <u>un-interrupted</u> for a <u>minimum</u> of 3 to 4 hours (<i>depending on boiler model</i>) after lighting, i.e. sufficient to allow all or most of the fuel to be burned out without stopping.</p> <p>Increase accumulator size or reduce amount of fuel loaded</p> <p>See page 21 for typical settings (HTX boiler range only).</p>
<p>2. As above <u>and</u> instability, boiler “panting” and excessive smoke</p>	<p>a) Glowing embers at rear of chamber will ignite all of fuel charge too quickly (<i>ignition should only be started at front</i>)</p>	<p>Ensure <u>no</u> glowing embers in boiler when re-loading, especially when using very small pieces of fuel. If however glowing embers are present, then pull them forward to front of chamber. <u>If</u> fire starts at the back, still ensure that good flame is also established at the front <u>before</u> starting the fan.</p>

Condition	Probable Cause	Remedy
2 cont.	<p>b) Poor flame establishment prior to fan starting</p> <p>c) Poor combustion immediately after fan started (<i>usually due to excess moisture in fuel</i>)</p> <p>d) Too much fuel loaded in boiler</p> <p>e) Fuel pieces too small, e.g. small offcuts, joinery waste, loose straw, woodchip, etc. causing too rapid gasification. Ratio of air space to surface area too high.</p> <p>f) Bottom of fuel load too loosely loaded with small pieces. This creates voids at base of fuel resulting in intense primary burn and production of excessive volumes of volatile gases in relation to available secondary air.</p> <p>g) 2 part base duct has separated or come out of alignment</p>	<p>Using small amount of kindling, light fire at bottom, front centre of fuel load and allow a good fire to establish using natural draft, with stoker door open. Could take 2 - 5 minutes. If flame does not establish readily, indicates damp fuel.</p> <p>Increase fan speed gradually over 5-10 minutes until operating speed is reached to prevent excess air "blowing" fire out.</p> <p>Reduce fuel load. Top 1/3 of boiler chamber <u>must</u> be left empty to provide sufficient space and dwell time to combust volatile gases.</p> <p>Balance fuel loads with larger pieces and load as below. If small pieces are used, stack as below.</p> <p>Load fuel tighter at the bottom to minimise voids in the fuel stack, adjusting air diverter (as required) to reduce primary air supply.</p> <p>Join together to prevent air leakage or replace. Clean any ash from beneath base duct sections as necessary to re-align parts.</p>
3. Excessive fuel use	<p>a) Excessive moisture in fuel</p> <p>b) Too much fuel loaded into the boiler</p> <p>c) Main fan timer set too long</p> <p>d) Inadequate thermostat control of heating system.</p> <p>e) Poor combustion</p> <p>f) Primary circulation pump to accumulator not controlled correctly (usually limit/pump thermostat)</p>	<p>Change fuel/fuel storage method and/or season fuel for longer period</p> <p>Reduce quantities</p> <p>Reduce fan running time to prevent fan cooling boiler after fuel charge has burned out.</p> <p>Add thermostatic controls and timer (e.g. <i>night set-back</i>)</p> <p>See above remedies</p> <p>Adjust to start circulation at approx. 75°C (<i>as high as possible, but always lower than the control stat setting</i>)</p>

Condition	Probable Cause	Remedy
3.cont	g) Insufficient level of insulation on pipework & accumulator.	
4. Boiler overheats	a) Open vent and cold feed incorrect. b) Air-locks in plumbing system. c) Inadequate heat leak. d) Limit/pump thermostat set too high (r.h.s of control box) e) Fan damper jammed open (non accumulator system). f) Air leaking through boiler door seals. g) Boiler oversized for heat load h) Control thermostat set too high. i) Pump inadequate or in wrong position j) Poor water circulation/air lock	Check with the installer against FARM2000 diagrams Check with the installer against FARM2000 diagrams (<i>there must be nowhere where air can get trapped</i>) Check with the installer against FARM2000 diagrams including the accumulator With accumulator, usually set at 75°C. When operates as override (<i>when no accumulator</i>) set to 90°C provided other control available (not relevant on HTR boilers) Renew seals every 2-3 years or as required Add accumulator and / or reduce fuel loading Recommended setting 80-85°C Contact heating engineer Check system, bleed radiators or consult heating engineer
5. Base duct distorts or bends (<i>usual operating life 3 - 6 years</i>)	a) Not being adequately air cooled due to prolonged idling, i.e. fan not running. b) No longer correctly positioned, air nozzle on door does not locate in base duct when door closed c) Door nozzle does not locate into duct.	Make sure all fuel is burned through without interruption (see boiler operation) Re-position base duct with entry gate just forward of stops in bottom of boiler chamber Raise rear of base duct using a brick or similar to align entry gate at front of base duct with air nozzle on door. Ensure 2 part base ducts are correctly joined.

